





















- A1.** As a means of assessing the durability of the bonding in bonded, laminated and fused fabric, it is frequently considered desirable to conduct the bond strength test after the fabric has undergone laundering, dry cleaning and/or saturation processes.
- A2.** The pretreatments used should be as agreed between the interested parties. Some widely accepted pretreatments are as follows:
- A2.1** Dry-clean the fabric three times in accordance with CAN/CGSB-4.2 No. 66-M and test specimens which have been conditioned in accordance with CAN/CGSB-4.2 No. 2-M.
- A2.2** Dry-clean the fabric three times in accordance with CAN/CGSB-4.2 No. 66-M and test specimens which are saturated with tetrachloroethylene (perchloroethylene) (Note A1).
- A2.3** Dry-clean the fabric three times in accordance with CAN/CGSB-4.2 No. 66-M and test specimens which are saturated with water. This procedure is usually used for flame-laminated fabrics.
- A2.4** Launder the fabric five times in accordance with CAN/CGSB-4.2 No. 67-M and test specimens which have been conditioned in accordance with CAN/CGSB-4.2 No. 2-M.
- A2.5** Launder the fabric five times in accordance with CAN/CGSB-4.2 No. 67-M and test specimens which are saturated with water.

Withdrawn

---

*Note A1: Perchloroethylene is toxic and the usual precaution for handling chlorinated solvents should be taken. It should be used only in well-ventilated areas. The solvent is nonflammable.*